



24 FEB 2005

## Installing X-10 Page into the GEWA Progress

This procedure is for Adding Pages to the GEWA *Progress*. The X-10 Page is preset with the X-10 Codes.

1. Copy the X-10 Page file to a PC
2. Back-up the *Progress* to its Memory Card:  
On the *Progress* main page...  
Select **TOOLS > Settings > System > Backup > Backup > Continue**
3. Turn off the *Progress*
4. Remove the memory card and insert it in a card reader in the PC
5. Paste the X-10 Page file to the memory card
6. Remove the memory card from the PC and insert it into the *Progress*
7. Turn on the *Progress* and press the Reset iPAQ button on the controls panel  
(The screen will show Updating)
8. Select: **Exit > Exit Progress**
9. Select: **Start > Programs > File Explorer > My Device > Storage Card**
10. Copy the X-10 Page File  
(Hold the pen on the file name until the window opens and select **Copy**)
11. Select: **My Device > Gewa > System > Default Pages**
12. Paste the X-10 Page file  
(At the bottom of the list, touch and hold the pen until the window opens and select **Paste**)
13. Exit (Select the **X** in the upper right of the screen)
14. Exit that screen, select: **Start > Progress**  
(The screen will show Loading and Updating)
15. Select: **Settings > Pages/Buttons > Add/Remove Page > Add Page > Add a Completed Page > Previous Page Select this Page > Done**
16. Go to **Start Page** to see the X-10 Page indicated
17. Select the X-10 Page button to see the X-10 page
18. BACK-UP!



installing the x-10 page into the progress.doc